



5

5、Assemble the seat part and fixed with screws



6

6、Rotate into the base seat plate, adjusting to the required height




Each product contains

| Number | Picture | Quantity | Number | Picture | Quantity | Additional accessories |
|--------|---------|----------|--------|---------|----------|------------------------|
| ①      |         | 1        | ⑦      |         | 3        | 1                      |
| ②      |         | 1        | ⑧      |         | 3        | 1                      |
| ③      |         | 1        | ⑨      |         | 3        | 1                      |
| ④      |         | 1        |        |         |          |                        |
| ⑤      |         | 1        |        |         |          |                        |
| ⑥      |         | 3        |        |         |          |                        |

X 1


P&W-016



Assembly instructions


1

1、Insert three legs in the end firmly according picture direction showed,you can use hammer and other tools.




2

2、Put into the round Crosspiece, note up and down direction



3

3、Tighten the screws and fix it.



4

4、put a small cover according picture showed, and secured with screws.

the side with countersunk holes outwards.

