



Assembly Instruction

GT-400A




A



1 pc

B



1 pc

C



1 pc

D



M6*20

4 pcs

E



M6*2

4 pcs

F



M8*25

2 pcs

G



M6

4 pcs

H



M8

1 pc

I



M6

1 pc