ASSEMBLY INSTRUCTION

DINING TABLE

Read instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling, place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTION :

1. Do not FULLY-TIGHTEN the nuts or nut bolts until all are in place.
2. To prevent thread damage, ensure that nuts or nut bolts are not over tighten.
3. Hardware are to be kept out reach from children.


PART LIST

ITEM	DESCRIPTION	QTY
A	TABLE TOP	1 PC
B	TABLE LEG BIG	2 PCS
C	TABLE LEG L	2 PCS
D	TABLE LEG R	2 PCS
E	MOUNTING PLATE	2 PCS


HARDWARE LIST

ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 X 100MM	4 PCS
2	JCBC BOLT M6 X 55MM	2 PCS
3	JCBC BOLT M6 X 30MM	22 PCS
4	SPRING WASHER 5/16" (RB)	28 PCS
5	WOOD DOWEL M10x30	4 PCS
6	SCREW PIN	4 PCS
7	ALLEN KEY M4 (BALL SHAPE)	1 PC
8	ADJUSTABLE SCREW 6x23MM	8 PCS


STEP 1




* Unscrew & dispose 2pcs JCBC screw from Mounting Plate | Table Top



STEP2



STEP 3



2266T

ASSEMBLY INSTRUCTION

DINING TABLE

Read instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling, place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTION :

1. Do not FULLY-TIGHTEN the nuts or nut bolts until all are in place.

2. To prevent thread damage, ensure that nuts or nut bolts are not over tighten.

3. Hardware are to be kept out reach from children.


PART LIST

ITEM	DESCRIPTION	QTY
A	TABLE TOP	1 PC
B	TABLE LEG BIG	2 PCS
C	TABLE LEG L	2 PCS
D	TABLE LEG R	2 PCS
E	MOUNTING PLATE	2 PCS

HARDWARE LIST


ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 X 100MM	4 PCS
2	JCBC BOLT M6 X 55MM	2 PCS
3	JCBC BOLT M6 X 30MM	22 PCS
4	SPRING WASHER 5/16'' (RB)	28 PCS
5	WOOD DOWEL M10x30	4 PCS
6	SCREW PIN	4 PCS
7	ALLEN KEY M4 (BALL SHAPE)	1 PC
8	ADJUSTABLE SCREW 6x23MM	8 PCS

STEP 4




*Screw JCBC with not to tight

STEP 5



STEP 6



Caution!

Repeat step 1 - 6 for 1 more unit of table leg assy before assemble with top board.

ASSEMBLY INSTRUCTION

DINING TABLE

Read instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling, place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTION :

1. Do not FULLY-TIGHTEN the nuts or nut bolts until all are in place.

2. To prevent thread damage, ensure that nuts or nut bolts are not over tighten.

3. Hardware are to be kept out reach from children.


PART LIST

ITEM	DESCRIPTION	QTY
A	TABLE TOP	1 PC
B	TABLE LEG BIG	2 PCS
C	TABLE LEG L	2 PCS
D	TABLE LEG R	2 PCS
E	MOUNTING PLATE	2 PCS


HARDWARE LIST


ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 X 100MM	4 PCS
2	JCBC BOLT M6 X 55MM	2 PCS
3	JCBC BOLT M6 X 30MM	22 PCS
4	SPRING WASHER 5/16'' (RB)	28 PCS
5	WOOD DOWEL M10x30	4 PCS
6	SCREW PIN	4 PCS
7	ALLEN KEY M4 (BALL SHAPE)	1 PC
8	ADJUSTABLE SCREW 6x23MM	8 PCS

STEP 7



STEP 8





DINING TABLE
COMPLETED ASSEMBLY

2266T