ASSEMBLY INSTRUCTION

DINING TABLE

Read instruction carefully. Refer hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling, place all wooden furniture part on a clean and flat soft surface to prevent scratches. Refer steps provided as assembling guide.

CAUTION :

1. Do not FULLY-TIGHTEN the nuts or nut bolts until all are in place.

2. To prevent thread damage, ensure that nuts or nut bolts are not over tighten.

3. Hardware are to be kept out reach from children.


PART LIST

ITEM	DESCRIPTION	QTY
A	TABLE TOP	1 PCS
B	TABLE LEG	4 PCS
C	SQUARE PLATE	1 PC


HARDWARE LIST

ITEM	DESCRIPTION	QTY
1	JCBC BOLT M6 X 50MM	4 PCS
2	JCBC BOLT M6 X 30MM	8 PCS
3	SPRING WASHER 5/16"	16 PCS
4	FLAT WASHER 6x13	8 PCS
5	ALLEN KEY M4	1 PC


STEP 1




STEP 2



STEP 3





COMPLETED ASSEMBLY

2276T